

## How to use Blink Charging Station:

- 1) Plug in your vehicle**
- 2) Download or open Blink mobile app**

Google/Android:

<https://play.google.com/store/search?q=blink%20charging&c=apps>

Apple: <https://apps.apple.com/us/app/blink-charging-mobile-app/id1612678852>

- 3) Login or charge as guest**
  - a. If charging as a guest, your email will still be required to agree to their terms of service. You will also be required to enter your billing address and card information.
- 4) Search for charging stations by zip code (50109), or by allowing the app to use your location**
- 5) Choose the charger number corresponding to the number on your pump handle**
- 6) Click “Start Charge”—a circle will start that says “connect the car to the charger” if you haven’t already plugged in**
- 7) Once completed, you can simply unplug. Charging session should end within the app**